

# Model # 7411 / 7411M

11PC. 1/2" DR FLANK BITE DAMAGED FASTENER IMPACT SOCKETS SAE / METRIC

# <complex-block>

### • ALSO SAFE FOR FORWARD TIGHTENING OF FASTENERS WITHOUT DAMAGE

## • MADE ONLY FROM 100% CRO-MO

MODEL	Set includes:
7411	• SAE Kit Includes: 10PC 5/16", 3/8", 7/16", 1/2", 9/16", 5/8", 11/16", 3/4", 13/16", 7/8" 1PC Punch Bar
7411M	<ul> <li>Metric Kit Includes: 10PC 8mm, 10mm, 11mm, 12mm, 13mm, 14mm, 15mm, 16mm, 17mm, 19mm 1PC Punch Bar</li> </ul>

SHOP EOUIPMENT

### 372 OLD US HIGHWAY 52 SOUTH MT. AIRY, NC 27030 (800) 221-9705 Phone: (336) 786-6432

SALES AND MARKETING 2417 SEAMAN AVENUE SOUTH EL MONTE, CA 91733

Phone: (800) 221-9705

**USA Toll Free** 

Fax: (336) 786-4992



 Traditional flank drive designs begin to round the points as torque exceeds the SAE limits of a fastener FLANK BITE

• Flank bite does not depend on the points of a fastener. The more torque is applied, the more it bites into only the sides



E-mail : astrotools@astrotools.com WEBSITE : www.astrotools.com



UNDERCAR KIT HYDRAULICS HAND TOOLS



AIR TOOLS